

<u>TAKEOFF RUNWAY 17:</u> Climbing left turn to 3000 heading 020° and on CVO R-081 to SHEDD INT, thence. . . .

TAKEOFF RUNWAYS 28, 35: Climbing right turn to 3000 heading 150° and on CVO R-081 to SHEDD INT, thence. . . .

. . . . on assigned route of flight.

LOST COMMUNICATIONS

NW-1, 22 FEB 2024

đ

21 MAR 2024

If not in contact with air traffic control upon reaching 3000, continue climb to assigned altitude direct CVO VOR/DME. Thence on assigned route of flight.