

ILS Z or LOC Z RWY 11
KETCHIKAN INTL (KTN)(PAKT)

MALSR 	MISSED APPROACH: Climb to 5000 direct CMJ NDB and on CMJ NDB bearing 124° to UCARU1-ECH 6.6 DME and on ANN VOR/DME R-338 to ANN VOR/DME and hold.
	# S-ILS 11 missed approach requires minimum climb of 305 feet per NM to 4000. S-LOC 11 missed approach requires minimum climb of 235 feet per NM to 4000. If unable to meet climb gradients, see LOC R XWY 11.

(IF) MUSUE
210K

CLAM COVE
396 CMJ

MSA CMJ 25 NM
5800

NICHOLS
266 ICK

**Procedure NA for arrivals
on ANN VOR/DME
airway radials 290 CW 309.**

LOCALIZER 109.3
I-ECH
Chan 30

IAF ANNETTE ISLAND
117.1 ANN
Chan 118

ALTERNATE MISSED APCH FIX
NICHOLS
266 ICK

ELEV 92 **TDZE 92**

KETCHIKAN, ALASKA
Amdt 1 10NOV16
55°21'N-131°43'W
KETCHIKAN INTL (KTN)(PAKT)
ILS Z or LOC Z RWY 11